



SERVICE MANUAL

STEREO RADIO RECEIVER

This Service Manual contains information about the difference between CR-LA30 (TYPE:Y).
If requiring the other information, see Service Manual of the CR-LA30 (TYPE:Y)
(S/M Code No. 09-993-327-1N2).

ALTERATION LIST
MECHANICAL PARTS LIST 1/1

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。
If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
1	8Z-RC9-018-010		WINDOW DIAL YJ1LT<YJ1LT>
1	8Z-RC9-023-010		WINDOW DIAL YJ1PT<YJ1PT>
3	8Z-RC9-015-010		CAB, FRONT YJ1LT<YJ1LT>
3	8Z-RC9-020-010		CAB, FRONT YJ1PT<YJ1PT>
6	S0-503-300-001		KNOB, SL BAND ABS J034-1
8	8Z-RC9-016-010		CAB, REAR YJ1LT<YJ1LT>
8	8Z-RC9-021-010		CAB, REAR YJ1PT<YJ1PT>
9	8Z-RC9-017-010		D00R, BATT YJ1LT<YJ1LT>
9	8Z-RC9-022-010		D00R, BATT YJ1PT<YJ1PT>
13	87-B10-128-010		SCREW, M1.7-2
15	S0-401-760-001		CONTACT PLATE (THK 0.3)
17	S0-201-750-001		BATT SPRING(-)

COLOR NAME TABLE

Basic color symbol	Color	Basic color symbol	Color	Basic color symbol	Color
B	Black	C	Cream	D	Orange
G	Green	H	Gray	L	Blue
LT	Transparent Blue	N	Gold	P	Pink
R	Red	S	Silver	ST	Titan Silver
T	Brown	V	Violet	W	White
WT	Transparent White	Y	Yellow	YT	Transparent Yellow
LM	Metallic Blue	LL	Light Blue	GT	Transparent Green
LD	Dark Blue	DT	Transparent Orange		

